

## Porter P2 - Field Service Guide

### Preventive Maintenance Schedule

Every 250 operating hours: inspect the drive wheels for wear and clean the lidar lenses with a microfiber cloth.

Every 500 operating hours: replace the air filter and check the battery contactor torque (specification: 8 Nm).

Every 1,000 operating hours: perform a full calibration of the floor-marker camera and update the navigation firmware.

## Porter P2 - Field Service Guide

### Error Codes

E101: drive motor over-temperature. Allow the unit to cool for 20 minutes before restarting.

E204: lidar obstruction detected. Clean the sensor and clear the travel path.

E330: battery pack communication fault. Re-seat the swappable battery; if the fault persists, replace the pack.

For all unresolved faults, contact Halcyon technical support.